## TYPHOON H FLIGHT CHECK LIST

PRE-FLIGHT	1.	ST16 battery more than 50% charged	
	2.	SD card in camera and cover removed	
	3.	Camera lens clean, drone battery secured	
	4.	Props, arms, legs OK	
	5.	ST16 switches in proper position	
FLIGHT	1.	Place drone for takeoff, facing away	
	2.	Turn on ST16 first, then H	
	3.	Step away 15' or so, wait for initialization	
	4.	Check voltage of both units on screen	
	5.	Wait until you get 16 or more GPS Sats on the bird, and 10 or more on the ST16. (20 and 14 are great)	
	6.	Drone light solid purple, with white flashes	
	7.	Start props with Red button, altitude zeros	
	8.	In Angle Mode, Turtle Speed, lift off	
		to 12-15', hover	
	9.	Craft stable, test control sticks	
	10.	Raise legs, proceed with flight	
LANDING	1.	Video turned off	
	2.	Lower legs, turn off OA	
	3.	In Angle Mode, Turtle Speed, land craft	
	4.	Stop props with Red button, note voltage	
		remaining in ST16 and drone.	
	5.	Turn off craft first, then ST16	